

Nitrical TM is a nitric acid solution and is used for the rapid decalcification of bone. NitricalTM removes and binds all calcium in specimens being treated. Minimal distortion of tissue and cellular structure after the decalcification process make this an ideal product for your calcified tissues when Immunohistochemistry (IHC) procedures are *not* being considered. If IHC is part of the diagnostic workup, then Formical 4TM, Formical 2000TM, or Immunocal TM should be considered.

APPLICATIONS/INTENDED USE

Nitrical[™] may be used to process all types of calcified histological specimens.

Tissue containing calcium must undergo calcium removal before tissue processing for best results.

Fix tissue in 10% Neutral Buffered Formalin or other suitable tissue fixative such as Bouins, B5, or Zinc Formalin. The volume of fixative solution should be 20 times the tissue volume.

RESULTS

To determine the end point of the decalcification process use either x-ray or chemical end –point determination techniques. Do not use probes, needs, scalpels or bending as this may cause physical damage to the specimen.

PROCEDURE

- 1. Specimens must be fixed before exposure to an acid solution.
- 2. It is best to suspend the specimen so it is not in contact with any of the surfaces of the container. This allows exposure to all specimen surfaces and allows the precipitated calcium salts to sink to the bottom of the container.
- Small specimens should not be left in the solution overnight. If decalcification process is incomplete, wash it in water and return to fixative. Wash again before returning to the decalcification solution to complete the process.
- 4. Continue Step #3 until specimen is completely decalcified.
- 5. If decalcification time exceeds 24 hours, it is best to replace the decalcifying solution with fresh solution daily.
- 6. Please Note: If you plan to stain the section with a Potassium Ferrocyanide / HCL stain (Iron stain), a minimum 10 minute rinse after decalcification is recommended.
- 7. Process tissues, embed and cut per Lab SOP (Standard Operating Procedure)

STORAGE/ SAFETY

Storage: Room Temperature Refer to SDS for details-

Caution:

Always wear appropriate personal protective equipment to include gloves, eye protection and laboratory coats when working with chemicals.

TECHNICAL INFORMATION

- 1. If decalcification process was incomplete, surface decalcification techniques may be used.
- To surface decal: Place a small dish of Nitrical[™] on ice. Place the face of the block in the dish for 5-10 minutes. Rinse the block in cold water. Icing tends to make the block harder and the water shed tends to soften the tissue face. Icing will greatly reduce the amount of chattering, especially in large blocks. Be certain to rinse the block before it is placed on the microtome (decal solution is corrosive)
- Remember that bone has all of the same tissue elements as any other tissue and in order to demonstrate them effectively the specimens must be well fixed and carefully monitored during the decalcification process.

CONTACT INFORMATION

American MasterTech 1330 Thurman Street Lodi, CA 95240 Phone: 800-860-4073 Fax: 209-368-4136 www.americanmastertech.com

Should any of our materials fail to perform to our specifications, we will be pleased to provide replacements or give credit for the purchase price. The information given in this bulletin is to the best of our knowledge accurate, but no warranty is expressed or implied. It is the user's responsibility to determine the suitability for their own use of the products described herein, and since conditions of use are beyond our control, we disclaim all liability with respect to the use of any material supplied by us. Nothing contained herein shall be construed as a recommendation to use any product or to practice any violation of any law or government regulation. 27-May-2015